

SAA1610 Installation Instructions

www.ergomart.com | 888 420 3200

1

(hole 2" or larger)

2

Insert arm pin into completely attached and assembled mount

3

Attach tilter head/VESA plate to LCD

4

Slide tilter pin into end of arm

5

Adjust vertical tilt resistance on tilter head

6

7







Please call Ergomart at
888 420 3200
with your questions
www.ergomart.com

ERGOMART

Ergonomic solutions for office and light industrial work environments

SAA1610 Parts List

www.ergomart.com | 888 420 3200

ITEM	DESCRIPTION / PART NO.	QUANTITY
	Spacer-screw retainer 104887	4
	M4 x .7 x 18mm screw 704917	4
	FLEXmount screw plate 104753	1
	Cable clip 105104	1
	Lower cable clip 104484	1
	3mm hex key 701313	1

ERGOMART

Ergonomic solutions for office and light industrial work environments