


## TRP2718 WORKSTATION MONITOR ARM Installation Instructions




www.ergomart.com | 888 420 3200




Insert arm pin into completely attached and assembled mount.



Slide rotation prevention bracket (A) onto face of tilter. Attach backbar to tilter with screws (B) through the tilter hole pattern of your choice.



Slide tilter pin into end of arm, secure using dog washer with spacer (C, D, & E).




Attach monitor to backbar using screw (F).

\* Some monitors may require spacer (G) between the monitor and backbar.


#### **ERGOMART**

PAGE 1 OF 3


## TRP2718 WORKSTATION MONITOR ARM Installation Instructions




www.ergomart.com | 888 420 3200




Install mouse holder (I) to backbar in desired location with attached small Velcro strip. Attach large Velcro strips to bottom of keyboard, then attach keyboard to tray in desired location.



Adjust vertical tilt resistance on tilter head.



Increase resistance to rotation at articulation points by tightening small set screws. DO NOT OVERTIGHTEN.




Route monitor cable through arm and install cable caps as shown.

### **ERGOMART**

PAGE 2 OF 3

# TRP2718 WORKSTATION MONITOR ARM Parts List



#### www.ergomart.com | 888 420 3200

	ITEM	DESCRIPTION / PART NO.	QUANTITY
Α.		Rotation Prevention Bracket	1
В.	8 min	10-32 x 5/8" Phillips Flat Head Screw	4
C.		Dog Washer Spacer	1
D.		Dog Washer	1
E.	C)	10-32 x 3/8" FPhMS w/Lock Patch	1
F.		M4 x 18mm Phillips Pan Head Screw	4
G.		1/2" Spacer	4
Н.		Velcro	2
I.		Mouse Holder w/Velcro Strip	1
J.		7/32" Allen Wrench	1
K.		3/32" Allen Wrench	1
L.		Forearm Cap	1
М.		Endcap Bumper	1
N.	To the state of th	Cable Cap	1

### **ERGOMART**